

D Montageanweisung
 DK Installationsinstruktus
 ES Instrucciones de montaje
 F Instructions d'installation
 I Istruzioni di montaggio
 N Installationsinstruktioner
 NL Installatievoorschrift
 S Installation instruktioer
 FI Asennusohje

SW2, SW2-US Auxiliary Switch Kit for SmartAct Damper Actuators N20xx, N34xx, S05xx, S10xx, S20xx

INSTALLATION INSTRUCTIONS

1

100/230 Vac, 5 (3) A

2

3 (S05xx, S10xx, S20xx)

4

5

230 V + 230 V	✓
24 V + 24 V	✓
230 V + 24 V SELV	✓

6

7

8

AS1


A — S3
 B — S1
 C — S2

AS2


S6 — C
 S4 — D
 S5 — D

9 Setting AS1, AS2


10 Setting AS1 (e.g. to 30°)




11




12 Result (10 + 11)




13 Setting AS2 (e.g. to 75°)




14



15 Result (13 + 14)



15



E	result	setting	e.g. to
D	Ergebnis	Einstellen	Z.B.auf
DK	resultat	justering	f. eks
ES	resultado	ajuste	e.g. en
F	résultat	ajustment	p.a. au
I	risultato	aggiustaggio	p.e. in
N	resultat	justering	f. eks
NL	resultat	instellen	b.v.
S	resultat	inställning	ex.
FI	tulos	asetta	esim

Automation and Control Solutions

Honeywell GmbH
Böblinger Straße 17
D-71101 Schönaich
Phone: (49) 7031 63701
Fax: (49) 7031 637493
<http://europe.hbc.honeywell.com>